



INSTALLATION INSTRUCTIONS FOR RACE READY PERFORMANCE CUTOUTS

1. Install the RACE READY PERFORMANCE "Y" pipe by first cutting out a section of the exhaust pipe on your vehicle equal to the length of the longest side of the "Y" pipe. Then clamp or weld the "Y" pipe in place with the short side of the pipe facing the rear of the vehicle and turned in such a way as to make room for the cutout and allowing at least 2" of clearance between it and the floorboards, frame, wires, fuel lines, etc.
2. Bolt on the cutout using the supplied bolts and gasket. Also install the optional downturn pipe at this point if so desired.
******* NOTE ***** BE SURE THE CUTOUT IS CENTERED IN THE "Y" PIPE OPENING, OTHERWISE THE VALVE MAY NOT OPEN PROPERLY**
3. Mount the switch bracket in the desired location. Separate the switch "pigtail" from the main harness at the first coupler. (approx. 6" back from the switch) and install it in the bracket by simply pressing into place. Plug the main harness back into the switch "pigtail" and connect the wires as labeled. The wire labeled + should be connected to a circuit that is only on when the ignition key is in the "on" position. The wire marked - can be grounded on the frame, the body, or you can run a wire directly from the negative post on the battery. The plug or plugs on the other end of the harness can be routed through any number of existing holes in the firewall or under the carpet and out through the rubber plugs in the floorboard if there are any. And then connected to the cutout or cutouts depending on your application.
If you have any trouble with the installation, contact us at: techsupport@racereadypower.com.

You are now ready to go out and play!

- Open the cutouts all the way to get the most POWER and ATTENTION.
- Open them part way just enough to let everyone know you're NOT exactly STOCK.
- Close them to go back to stock and DISAPPEAR into the crowd.

WARNING!

- Keep away from cutouts when activating. Failure to do so may cause bodily injury.
- Do not drive vehicle off road with cutouts open. This could create a fire hazard.
- It is illegal in most states to bypass emission and exhaust systems.
- Any altering of the exhaust system may affect various electronic sensors and systems on some vehicles.
- RELEASE switch immediately upon valve reaching full open or full closed position. **Failure to do so may cause a fuse to blow or the cutout motor to fail.**
- If optional down turn pipe is used, be sure the exhaust is blowing away from the vehicle. Failure to do so may result in damage to your vehicle.
- When operating a motor vehicle, always do so in an open, well ventilated area.
- Always follow safety precautions when working on or around a motor vehicle.
- Always wear safety glasses and appropriate clothing when working on a motor vehicle.
- Always...ALWAYS...use common sense when working on a motor vehicle.

DISCLAIMER

Race Ready Performance LLC and its individual owner or owners, will not be held responsible in any way, shape or form for damages directly or indirectly caused by any of the products we sell or manufacture. It is the purchaser's responsibility to ensure the correct installation and application for any of our products. These products are recommended for racing applications only as they are not be street legal in most states. By installing or using this product, you are confirming that you have read and are agreeing to all of the terms and conditions stated on this page as well as all other pages included in this product.

WARRANTY

This policy is valid for the original owner of the Race Ready Performance electric exhaust cutout only and all of the following provisions must be met before Race Ready Performance will honor the warranty request.

- The Race Ready Performance warranty card must be filled out and submitted along with a copy of the original receipt within 30 days of purchase.
- The Race Ready Performance electric exhaust cutout must be installed by a qualified exhaust/performance shop.
- The Race Ready Performance electric exhaust cutout must be on the vehicle that it was originally registered to.
- The Race Ready Performance electric exhaust cutout will be replaced or repaired at our sole discretion.
- Within the first 12 months of purchase, Race Ready Performance will pay warranty related shipping costs one way, after that 12 month period ends, it will be the customers responsibility to pay for all shipping costs to and from our repair facility.

This warranty is non-transferable and is VOID if there is any indication of physical damage or abuse of any kind.

The terms and conditions of this policy may change without notice.

RETURN POLICY

Race Ready Performance will accept product returns within 14 days of purchase if all of the following conditions are met.

- The product was purchased directly from Race Ready Performance. (Otherwise, return it to the store where it was purchased and that stores return policy will apply)
- Customer must submit a copy of the original sales receipt.
- All contents must be free of any damage or blemishes of any kind and packages within the original box must be in new, unopened condition.
- Customer must call or email Race Ready Performance in advance and get an RMA (returned materials authorization) number which needs to be submitted with the returned product.
- Shipping charges will be the responsibility of the Customer. When the product is received and inspected by us, the refund will then be processed.

Terms and conditions of this policy may change without notice.

THANK YOU!

Now that all of the legal junk is out of the way, RACE READY PERFORMANCE wants to THANK YOU for your purchase. We sincerely appreciate your business and want you to always be ready to race. If we can help in any way, please call us at 1-866 RACE READY or visit us on the web at:

www.racereadyperformance.com or send us an email at: info@racereadyperformance.com